

# ARM X1 LITE

DYNASPRING Pat. Pend.

Emerald Green

Blue Breeze

Scarlet Red

Obsidian Black



To use this load chart, simply find the weight of your sled on the diagram to correctly select which combination of springs will give you the best results. The springs must be compressed to work properly. Never select a more powerful combination in respect to what you need for the actual load. If you find your arm spring combination to be near a red setpoint indicator on the chart, choose the combination that requires more preload and less number of springs to be fit rather than the other one (more springs number with less preload)

## PRELOAD CHART

